IntesisBox®

ME-AC-KNX-1i v1.0

User's Manual

Issue Date: 30/05/2012

r2 eng

© Intesis Software S.L. All Rights Reserved.

Information in this document is subject to change without notice. The software described in this document is furnished under a license agreement or nondisclosure agreement. The software may be used only in accordance with the terms of those agreements. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or any means electronic or mechanical, including photocopying and recording for any purpose other than the purchaser's personal use without the written permission of Intesis Software S.L.

Intesis Software S.L.
Milà I Fontanals, 1 bis, 1º
08700 Igualada
Spain

TRADEMARKS
All trademarks and trade names used in this document are acknowledged to be the copyright of their respective holders.

Gateway for integration of Mitsubishi Electric air conditioners into KNX TP-1 (EIB) control systems.

Compatible with Domestic and Mr. Slim line air conditioners commercialized by Mitsubishi Electric.

Application's Program Version: 1.0

Order Code: **ME-AC-KNX-1i**

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® *is a registered trademark of Intesis Software SL*

URL http://www.intesis.com
Email info@intesis.com
tel +34 938047134

INDEX

1. Presentation 6
2. Connection 7
3. Configuration and setup 8
4. ETS Parameters 9
4.1 General dialog 10
4.1.1 Send READs for Control_ objects on bus recovery 10
4.1.2 Scene to load on bus recovery / startup 10
4.1.3 Disallow control from remote controller 10
4.1.4 Enable func "Control_ Lock Control Obj" 11
4.1.5 Enable func "Operating Hours Counter" 11
4.1.6 Enable object "Error Code [2byte]" 12
4.1.7 Enable object "Error Text Code [14byte]" 12
4.2 Mode Configuration dialog 13
4.2.1 Indoor unit has FAN mode 13
4.2.2 Enable use of Heat / Cool bit-type obj 13
4.2.3 Enable PID-Compat. Scaling Mode Objects 14
4.2.4 Enable use of + / - object for Mode 15
4.2.5 Enable use of bit-type Mode objects (for control) 15
4.2.6 Enable use of bit-type Mode objects (for status) 16
4.2.7 Enable use of Text object for Mode 16
4.2.8 Enable use of Legacy_ object for Mode 16
4.3 Special Modes Configuration dialog 17
4.3.1 Enable use of POWER mode 17
4.3.2 Enable use of ECONOMY mode 18
4.3.3 Enable use of ADDITIONAL HEATING mode 19
4.3.4 Enable use of ADDITIONAL COOLING mode 20
4.4 Fan Speed Configuration dialog 21
4.4.1 Fan is accessible in Indoor unit 21
4.4.2 Available fanspeeds in Indoor Unit 21
4.4.3 Indoor unit has AUTO fan speed 22
4.4.4 DPT object type for fanspeed 22
4.4.5 Enable use of +/- object for Fan Speed 23
4.4.6 Enable "Fan Speed Manual/Auto" objects (for Control and Status) 24
4.4.7 Enable use of bit-type Fan Speed objects (for Control) 24
4.4.8 Enable use of bit-type Fan Speed objects (for Status) 25
4.4.9 Enable use of Text object for Fan Speed 25
4.4.10 Enable use of Legacy_ object for Fan Speed 26
4.5 Vanes Up-Down Configuration dialog 26
4.5.1 Indoor unit has U-D Vanes 26
4.5.2 Available positions in Indoor Unit 27
4.5.3 Indoor unit has AUTO Vanes U-D 27
4.5.4 DPT object type for Vanes Up-Down 27
4.5.5 Enable use of +/- object for Vanes U-D 28
4.5.6 Enable use of bit-type Vane U-D objects (for Control) 29
4.5.7 Enable use of bit-type Vane U-D objects (for Status) 30
4.5.8 Enable "Vanes U-D Man/Auto" objects (for Control and Status) 30
4.5.9 Enable "Vanes U-D Swing" objects (for Control and Status) 31
4.5.10 Enable use of Text object for Vane U-D 31
4.5.11 Enable use of Legacy_ object for Vanes 32
4.6 Temperature Configuration dialog 32
4.6.1 Periodic sending of "Status_ AC Setp" 32
4.6.2 Transmission of "Status_ AC Return Temp" 33
4.6.3 Enable use of +/- object for Setpoint Temp 33

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

4.6.4 Enable limits on Control_ Setpoint obj 34
4.6.5 Ambient temp. ref. is provided from KNX 34
4.7 Scene Configuration dialog 35
4.7.1 Enable use of scenes 35
4.7.2 Scenes can be stored from KNX bus 36
4.7.3 Enable use of bit objects for scene execution 36
4.7.4 Scene "x" preset 37
4.8 Switch-Off Timeouts Configuration dialog 39
4.8.1 Enable use of Open Window / Switch off timeout function 39
4.8.2 Enable use of Occupancy function 40
4.8.3 Enable use of SLEEP timeout 43
4.9 Binary Input "x" Configuration dialog 44
4.9.1 Enable use of Input "x" 44
4.9.2 Contact type 44
4.9.3 Debounce time 44
4.9.4 Disabling function 45
4.9.5 Function 45
5. Specifications 53
6. AC Unit Types compatibility. 54
7. Error Codes 55
Appendix A – Communication Objects Table 56

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

1. Presentation

ME-AC-KNX-1i allows a complete and natural integration of MITSUBISHI ELECTRIC air conditioners with KNX control systems.

Compatible with all Domestic and Mr. Slim models commercialized by MITSUBISHI ELECTRIC.

Main features:

- Reduced dimensions, quick installation.
- Multiple objects for control and status (bit, byte, characters…) with KNX standard datapoint types.
- Status objects for every control available.
- Timeout for Open Window and Occupancy. Sleep function also available.
- Control of the AC unit based in the ambient temperature read by the own AC unit, or in the ambient temperature read by any KNX thermostat.
- AC unit can be controlled simultaneously by the IR remote control of the AC unit and by KNX.
- Total Control and Monitoring of the AC unit from KNX, including monitoring of AC unit's state of internal variables, running hours counter (for filter maintenance control), and error indication and error code.
- Up to 5 scenes can be saved and executed from KNX, fixing the desired combination of Operation Mode, Set Temperature, Fan Speed, Vane Position and Remote Controller Lock in any moment by using a simple switching.
- Four potential-free binary inputs provide the possibility to integrate many types of external devices. Also configurable from ETS, they can be used for switching, dimming, shutter/blind control, and more

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

2. Connection

The interface comes with a cable (1,9 meters long) for direct connection to the internal control board of the AC indoor unit.

- Connection of the interface to the AC indoor unit:

Disconnect mains power from the AC unit. Open the front cover of the indoor unit in order to have access to the internal control board. In the control board locate the socket connector marked as:

CN92 in Mr. Slim models.
or
CN105 in rest of models.

Using the cable that comes with the interface, insert one of its connectors, the one installed in the shortest uncovered part, into the socket of the ME-AC-KNX-1i marked as **AC Unit**, and the other connector, the one in the largest uncovered part, into the socket **CN92** or **CN105** of the AC unit's control board. Fix the ME-AC-KNX-1i inside or outside the AC indoor unit depending on your needs, remember that ME-AC-KNX-1i must be also connected to the KNX bus. Close the AC indoor unit's front cover again.

⚠ ***Important***: Do not modify the length of the cable supplied with the interface, it may affect to the correct operation of the interface

- Connection of the interface to the KNX bus:

Disconnect power of the KNX bus. Connect the interface to the KNX TP-1 (EIB) bus using the KNX standard connector (red/grey) of the interface, respect polarity. Reconnect power of the KNX bus.

- Connections diagram:



Figure 2.2 Connection diagram

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

3. Configuration and setup

This is a fully compatible KNX device which must be configured and setup using standard KNX tool ETS.

ETS database for this device can be downloaded from:

http://www.intesis.com/down/eib/ME-AC-KNX-1i.zip

Please consult the README.txt file, located inside the downloaded zip file, to find instructions on how to install the database.

⚠ ***Important**: Do not forget to select the correct settings of AC indoor unit being connected to the ME-AC-KNX-1i. This is in "Parameters" of the device in ETS.*

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

4. ETS Parameters

When imported to the ETS software for the first time, the gateway shows the following default parameter configuration:


Device: 1.1.1 ME AC Interface
General
Mode Configuration
Special Modes Configuration
Fan Speed Configuration
Vanes Up-Down Configuration
Temperature Configuration
Scene Configuration
Switch-Off Timeouts Configuration
Binary Input 1 Configuration
Binary Input 2 Configuration
Binary Input 3 Configuration
Binary Input 4 Configuration
Download latest database entry for this product and its User Manual from:
http://www.intesis.com
Send READs for Control_ objects on bus recovery (T & U flags must be active)
No
Scene to load on bus recovery / startup (needs to define vals for that scene)
(none)
Disallow control from remote controller
No
> Enable comm obj "Ctrl_ Remote Lock"
No
Enable func "Control_ Lock Control Obj"
No
Enable func "Operating Hours Counter"
No
Enable object "Error Code [2byte]"
No
Enable object "Error Text Code [14byte]" (4 ASCII-char Error Code)
Yes

Figure 4.1 Default parameter configuration

With this configuration it's possible to send On/Off (*Control_ On/Off*), change the AC Mode (*Control_ Mode*), the Fan Speed (*Control_ Fan Speed*) and also the Setpoint Temperature (*Control_ Setpoint Temperature*). The Status_ objects, for the mentioned Control_ objects, are also available to use if needed. Also objects *Status_ AC Return Temp* and *Status_ Error/Alarm* are shown.


1.1.1 ME AC Interface
0: Control_ On/Off [DPT_1.001 - 1bit] - 0-Off;1-On
1: Control_ Mode [DPT_20.105 - 1byte] - 0-Aut;1-Hea;3-Coo;9-Fan;14-Dry
11: Control_ Fan Speed / 2 Speeds [DPT_5.001 - 1byte] - Threshold: 75%
27: Control_ Setpoint Temperature [DPT_9.001 - 2byte] - (ºC)
54: Status_ On/Off [DPT_1.001 - 1bit] - 0-Off;1-On
55: Status_ Mode [DPT_20.105 - 1byte] - 0-Aut;1-Hea;3-Coo;9-Fan;14-Dry
63: Status_ Fan Speed / 2 Speeds [DPT_5.001 - 1byte] - 50% and 100%
79: Status_ AC Setpoint Temp [DPT_9.001 - 2byte] - (ºC)
80: Status_ AC Return Temperature [DPT_9.001 - 2byte] - (ºC)
81: Status_ Error/Alarm [DPT_1.005 - 1bit] - 0-No alarm;1-Alarm
83: Status_ Error Text Code [DPT_16.001 - 14byte] - 4 char ME Error;Empty-None

Figure 4.2 Default communication objects

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

4.1 General dialog

Inside this parameter's dialog it is possible to activate or change the parameters shown in the **Figure 4.1**.

The first field shows the URL where to download the database and the user manual for the product.

4.1.1 Send READs for Control_ objects on bus recovery

When this parameter is enabled, ME-AC-KNX-1i will send READ telegrams for the group addresses associated on its *Control_* objects on bus recovery or application reset/start-up.

- If set to **"no"** the gateway will not perform any action.
- If set to **"yes"** all *Control_* objects with both Transmit **(T)** and Update **(U)** flags enabled will send READs and their values will be updated with the response when received.



Figure 4.3 Parameter detail

- Delay before sending READs (sec):

  With this parameter, a delay can be configured between 0 and 30 seconds for the READs sent by the *Control_* objects. This is to give time enough to other KNX devices on the bus to start-up before sending the READs.

4.1.2 Scene to load on bus recovery / startup

This parameter executes a selected scene on bus recovery or startup, only if the selected scene has an enabled preset or values previously saved from KNX bus (see Scene Configuration dialog).

If the gateway is disconnected from the indoor unit the scene will not be applied, even when connecting to the indoor unit again.



Figure 4.4 Parameter detail

4.1.3 Disallow control from remote controller

This parameter allows:

1- Having the remote controller always locked, or
2- Decide through a new communication object if the RC is locked or not.

- If set to **"yes"** all the actions performed through the remote controller will be disabled.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

- If set to **"no"** the remote controller will work as usually. It also appears a new parameter and the communication object *Control_ Lock Remote Control*.


33: Control_ Lock Remote Control [DPT_1.002 - 1bit] - 0-Unlocked;1-Locked
Disallow control from remote controller
no
> Enable comm obj "Ctrl_ Remote Lock"
yes

Figure 4.5 Communication object and parameter detail

➢ Enable comm obj "Ctrl_ Remote Lock":

If set to **"no"** the object will not be shown.

If set to **"yes"** the *Control_ Lock Remote Control* object will appear.

- When a **"1"** value is sent to this communication object, the remote controller is locked. To be unlocked a **"0"** value must be sent. The gateway remembers the last value received even if a KNX bus reset/failure happens.

⚠ ***Important:*** *If an initial scene is enabled and it has as Value for Remote Lock (unchanged) or unlocked, this would unlock the remote controller because the initial scene has priority over the Control_ Lock Remote Control communication object.*

4.1.4 Enable func "Control_ Lock Control Obj"

This parameter shows/hide the *Control_ Lock Control Obj* communication object which, depending on the sent value, locks or unlocks ALL the *Control_* communication objects except itself.



- If set to **"no"** the object will not be shown.
- If set to **"yes"** the *Control_ Lock Control Objects* object will appear.

  - When a **"1"** value is sent to this communication object, all the *Control_* objects will be locked. To unlock a **"0"** value must be sent, as the gateway remembers the last value received even if a KNX bus reset/failure happens.

4.1.5 Enable func "Operating Hours Counter"

This parameter shows/hides the *Status_ Operation Hour Counter* communication object which counts the number of operating hours for the ME-AC-KNX-1i.



- If set to **"no"** the object will not be shown.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

- If set to **"yes"** the *Status_ Operation Hour Counter* object will appear.

    - This object can be read and sends its status every time an hour is counted. The gateway keeps that count in memory and the status is sent also after a KNX bus reset/failure. Although this object is marked as a *Status_* object it also can be written to update the counter when needed. To reset the counter should be written a **"0"** value.

    ⚠ ***Important:*** *This object comes by default without the write* ***(W)*** *flag activated. If is necessary to write on it, this flag must be activated.*

    ⚠ ***Important:*** *This object will also return its status, every time a value is written, only if it's different from the existing one.*

    ⚠ ***Important:*** *If the stored value is 0 hours, the gateway will not send the status to KNX.*

4.1.6 Enable object "Error Code [2byte]"

This parameter shows/hides the *Status_ Error Code* communication object which shows the indoor unit errors, if occurred, in numeric format.



- If set to **"no"** the object will not be shown.
- If set to **"yes"** the *Status_ Error Code [2byte]* object will appear.

    - This object can be read and also sends the indoor unit error, if occurred, in numeric format. If a **"0"** value is shown that means no error.

4.1.7 Enable object "Error Text Code [14byte]"

This parameter shows/hides the *Status_ Error Text Code* communication object which shows the indoor unit errors, if occurred, in text format.



- If set to **"no"** the object will not be shown.
- If set to **"yes"** the *Status_ Error Text Code* object will appear.

    - This object can be read and also sends the indoor unit error, if occurred, in text format. The errors shown have the same format as at the remote controller and at the error list from the indoor unit manufacturer. If the object's value is empty that means no error.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

4.2 Mode Configuration dialog


Device: 1.1.1 ME AC Interface
General
Mode Configuration
Special Modes Configuration
Fan Speed Configuration
Vanes Up-Down Configuration
Temperature Configuration
Scene Configuration
Switch-Off Timeouts Configuration
Binary Input 1 Configuration
Binary Input 2 Configuration
Binary Input 3 Configuration
Binary Input 4 Configuration
Indoor unit has FAN mode (see docum. for your indoor unit)
Yes
Enable "Mode Cool/Heat" objects (for Control and Status)
No
Enable PID-Compat. Scaling Mode objects (for Control)
No
Enable use of +/- object for Mode
No
Enable use of bit-type Mode objects (for Control)
No
Enable use of bit-type Mode objects (for Status)
No
Enable use of Text object for Mode
No
Enable use of Legacy_ object for Mode (compatible with old vers of XXACKNX1)
No

Figure 4.6 Default Mode Configuration dialog

All the parameters in this section are related with the different mode properties and communication objects.



The byte-type communication object for Mode works with the DTP_20.105. Auto mode will be enabled with a **"0"** value, Heat mode with a **"1"** value, Cool mode with a **"3"** value, Fan mode with a **"9"** value and Dry mode with a **"14"** value.

4.2.1 Indoor unit has FAN mode

This parameter has to be used to indicate if the indoor unit has the *fan mode* available.

- If set to **"no"**, the indoor unit doesn't have the *fan mode* available.
- If set to **"yes"**, the infoor unit has the *fan mode* available.

⚠ ***Important:*** *Read the documentation of your indoor unit to check if it has FAN mode available.*

4.2.2 Enable use of Heat / Cool bit-type obj

This parameter shows/hides the *Control_* and *Status_ Mode Cool/Heat* communication objects.



- If set to **"no"** the objects will not be shown.
- If set to **"yes"** the *Control_* and *Status_ Mode Cool/Heat* objects will appear.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

- When a **"1"** value is sent to the *Control_* communication object, **Heat mode** will be enabled in the indoor unit, and the *Status_* object will return this value.

- When a **"0"** value is sent to the *Control_* communication object, **Cool mode** will be enabled in the indoor unit, and the *Status_* object will return this value.

4.2.3 Enable PID-Compat. Scaling Mode Objects

This parameter shows/hides the *Control_ Mode Cool & On* and *Control_ Mode Heat & On* communication objects.



- If set to **"no"** the objects will not be shown.

- If set to **"yes"** the *Control_ Mode Cool & On* and *Control_ Mode Heat & On* objects will appear.

    - These objects provide compatibility with those KNX thermostats that control the demand of heating or cooling by using scaling (percentage) objects. In these thermostats, the percentage demand is meant to be applied on a fluid valve of the heating / cooling system.

    - ME-AC-KNX-1i device does not provide individual control on the internal parts of the indoor unit (as can be its compressor, refrigerant valves, etc). Rather, it provides the same level of control as a (user) remote controller.

    - Objects "Control_ Mode Cool & On" and "Control_ Mode Heat & On" intend to bring compatibility between thermostats oriented to the control of custom heating / cooling systems and ready-made AC indoor units, by applying the following logic:

        - Whenever a non-zero value (>0%) is received at "Control_ Mode Cool & On", indoor unit will switch On in COOL mode.

        - Whenever a non-zero value (>0%) is received at "Control_ Mode Heat & On", indoor unit will switch On in HEAT mode.

            - Lastest updated object will define the operating mode

        - Indoor unit will switch off only when both objects become zero (0%) – or when an OFF is requested at object "0. On/Off [DPT_1.001 - 1bit]"

⚠ ***Important:*** *These objects function is only to send On/Off and Cool/Heat to the indoor unit. The PID (Inverter system) is calculated by the indoor unit itself. Please consider introducing an appropriate PID configuration to the external KNX thermostat to not interfere the indoor unit PID.*

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

4.2.4 Enable use of + / - object for Mode

This parameter shows/hides the *Control_ Mode +/-* communication object which lets change the indoor unit mode by using two different datapoint types.



- If set to **"no"** the object will not be shown.
- If set to **"yes"** the *Control_ Mode +/-* object and a new parameter will appear.



Figure 4.7 Parameter detail

➢ DPT type for +/- Mode Object

This parameter lets choose between the datapoints **0-Up / 1-Down [DPT_1.008]** and **0-Decrease / 1-Increase [DPT_1.007]** for the *Control_ Mode +/-* object.

The sequence followed when using this object is shown below:

- Up / Increase
- Down / Decrease

⚠ ***Important:*** *Read the documentation of your indoor unit to check if it has FAN mode available.*

4.2.5 Enable use of bit-type Mode objects (for control)

This parameter shows/hides the bit-type *Control_ Mode* objects.


5: Control_ Mode Auto [DPT_1.002 - 1bit] - 1-Set AUTO mode
6: Control_ Mode Heat [DPT_1.002 - 1bit] - 1-Set HEAT mode
7: Control_ Mode Cool [DPT_1.002 - 1bit] - 1-Set COOL mode
8: Control_ Mode Fan [DPT_1.002 - 1bit] - 1-Set FAN mode
9: Control_ Mode Dry [DPT_1.002 - 1bit] - 1-Set DRY mode

- If set to **"no"** the objects will not be shown.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

- If set to **"yes"** the *Control_ Mode* objects for Auto, Heat, Cool, Fan and Dry will appear. To activate a mode by using these objects a **"1"** value has to be sent.

4.2.6 Enable use of bit-type Mode objects (for status)

This parameter shows/hides the bit-type *Status_ Mode* objects.


57: Status_ Mode Auto [DPT_1.002 - 1bit] - 1-AUTO mode is active
58: Status_ Mode Heat [DPT_1.002 - 1bit] - 1-HEAT mode is active
59: Status_ Mode Cool [DPT_1.002 - 1bit] - 1-COOL mode is active
60: Status_ Mode Fan [DPT_1.002 - 1bit] - 1-FAN mode is active
61: Status_ Mode Dry [DPT_1.002 - 1bit] - 1-DRY mode is active

- If set to **"no"** the objects will not be shown.
- If set to **"yes"** the *Status_ Mode* objects for Auto, Heat, Cool, Fan and Dry will appear. When enabled, a mode will return a **"1"** through its bit-type object.

4.2.7 Enable use of Text object for Mode

This parameter shows/hides the *Status_ Mode Text* communication object.



- If set to **"no"** the object will not be shown.
- If set to **"yes"** the *Status_ Mode Text* object will appear. Also, in the parameters, will be shown five text fields, one for each mode, that will let modify the text string displayed by the *Status_ Mode Text* when changing mode.



Figure 4.8 Parameter detail

4.2.8 Enable use of Legacy_ object for Mode

This parameter shows/hides the *Legacy_ Mode* communication object



- If set to **"no"** the communication object will not be shown.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

- If set to **"yes"** the *Legacy_ Mode* communication object will appear. This object lets change the indoor unit mode but it uses a different data type. It is used to maintain compatibility with old gateway models.

4.3 Special Modes Configuration dialog



Figure 4.9 Default Special Modes Configuration dialog

The Special Modes can be parameterized through the ETS parameters dialog, and they can be used to give extra functionality.

⚠ ***Important:*** *When executing any of the Special Modes the real state of the indoor unit will NOT be shown in KNX.*

⚠ ***Important:*** *When the predefined time for the Special Mode is finished or a **"0"** value is sent to stop it, the previous state will be recovered.*

⚠ ***Important:*** *If a value concerning On/Off, Mode, Fan Speed or Setpoint Temperature is received from KNX while any Special Mode is running (**"1"**), the Special Mode will stop and the previous state will be recovered. The value received will be also applied then.*

⚠ ***Important:*** *If a value concerning On/Off, Mode, Fan Speed or Setpoint Temperature is modified through the remote controller, the Special Mode will stop WITHOUT recovering the previous state. Then the real indoor unit state will be shown in KNX including the new value received through the remote controller.*

4.3.1 Enable use of POWER mode

This parameter shows/hides the *Control_ Power Mode* and *Status_ Power Mode* communication objects. The Power Mode lets change the Setpoint Temperature and the Fan Speed within a given period of time.



- If set to **"no"** the objects will not be shown.
- If set to **"yes"** the *Control_ Power Mode* and *Status_ Power Mode* objects and new parameters will appear.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL


Enable use of POWER mode
yes
> Action time for this mode (minutes) (0 = permanent / unlimited)
2
> Setpoint delta increase (HEAT) or decrease (COOL) - in Celsius
2.0°C
> Fanspeed for this mode
SPEED 3 (if avail.)

Figure 4.10 Parameter detail

- When a **"1"** value is sent to the *Control_* communication object Power Mode will be enabled, and the *Status_* object will return this value.
- When a **"0"** value is sent to the *Control_* communication object, Power Mode will be disabled, and the *Status_* object will return this value.

⚠ ***Important:*** *This mode will ONLY work if the indoor unit is both turned on and in a Heat, Cool, Auto-Heat or Auto-Cool Mode.*

➢ Action time for this mode (minutes):

Duration of Power Mode, in minutes, once started.

➢ Setpoint delta increase (HEAT) or decrease (COOL) – in Celsius:

Number of degrees Celsius that will increase in Heat Mode, or decrease in Cool Mode, while in Power Mode.

➢ Fan Speed for this mode:

Fan Speed that will be set in the unit while in Power Mode.

4.3.2 Enable use of ECONOMY mode

This parameter shows/hides the *Control_ Econo Mode* and *Status_ Econo Mode* communication objects. The Econo Mode lets change the Setpoint Temperature and the Fan Speed within a given period of time.



- If set to **"no"** the objects will not be shown.
- If set to **"yes"** the *Control_ Econo Mode* and *Status_ Econo Mode* objects and new parameters will appear.
  - When a **"1"** value is sent to the *Control_* communication object, EconoMode will be enabled, and the *Status_* object will return this value.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

- When a **"0"** value is sent to the *Control_* communication object, EconoMode will be disabled, and the *Status_* object will return this value.

⚠ ***Important:*** *This mode will ONLY work if the indoor unit is both turned on and in a Heat, Cool, Auto-Heat or Auto-Cool Mode.*

➢ Action time for this mode (minutes):

Duration of EconoMode, in minutes, once started.

➢ Setpoint delta increase (HEAT) or decrease (COOL) – in Celsius:

Number of degrees Celsius that will increase in Heat Mode, or decrease in Cool Mode, while in EconoMode.

➢ Fan Speed for this mode:

Fan Speed that will be set in the unit while in EconoMode.

4.3.3 Enable use of ADDITIONAL HEATING mode

This parameter shows/hides the *Control_ Start Additional Heat Mode* and *Status_ Additional Heat Mode* communication objects. The Additional Heating Mode lets change the Setpoint Temperature and the Fan Speed within a given period of time.



- If set to **"no"** the objects will not be shown.
- If set to **"yes"** the Control_ Start Additional Heat Mode and Status_ Additional Heat Mode objects and new parameters will appear.

  - When a **"1"** value is sent to the *Control_* communication object, Additional Heating Mode will be enabled, and the *Status_* object will return this value.
  - When a **"0"** value is sent to the *Control_* communication object, Additional Heating Mode will be disabled, and the *Status_* object will return this value.

  ⚠ ***Important:*** *This mode will ALWAYS turn on the indoor unit in Heat mode.*

➢ Action time for this mode (minutes):

Duration of Additional Heating Mode, in minutes, once started.

➢ Setpoint temp for this mode (ºC):

Setpoint temperature that will be applied while in Additional Heating Mode.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

➢ Fan Speed for this mode:

Fan Speed that will be set in the unit while in Additional Heating Mode.

4.3.4 Enable use of ADDITIONAL COOLING mode

This parameter shows/hides the *Control_ Start Additional Cool Mode* and *Status_ Additional Cool Mode* communication objects. The Additional Heating Mode lets change the Setpoint Temperature and the Fan Speed within a given period of time.



- If set to **"no"** the objects will not be shown.
- If set to **"yes"** the Control_ Start Additional Cool Mode and Status_ Additional Cool Mode objects and new parameters will appear.
    - When a **"1"** value is sent to the *Control_* communication object, Additional Cooling Mode will be enabled, and the *Status_* object will return this value.
    - When a **"0"** value is sent to the *Control_* communication object, Additional Cooling Mode will be disabled, and the *Status_* object will return this value.

    ⚠ ***Important:*** *This mode will ALWAYS turn on the indoor unit in Cool mode.*

➢ Action time for this mode (minutes):

Duration of Additional Cooling Mode, in minutes, once started.

➢ Setpoint temp for this mode (ºC):

Setpoint temperature that will be applied while in Additional Cooling Mode.

➢ Fan Speed for this mode:

Fan Speed that will be set in the unit while in Additional Cooling Mode.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

4.4 Fan Speed Configuration dialog


Device: 1.1.1 ME AC Interface
General
Mode Configuration
Special Modes Configuration
Fan Speed Configuration
Vanes Up-Down Configuration
Temperature Configuration
Scene Configuration
Switch-Off Timeouts Configuration
Binary Input 1 Configuration
Binary Input 2 Configuration
Binary Input 3 Configuration
Binary Input 4 Configuration
Fan is accessible in Indoor unit (see docum. for your indoor unit)
Yes
Available fanspeeds in Indoor Unit (see docum. for your indoor unit)
2
Indoor unit has AUTO fan speed (see docum. for your indoor unit)
No
DPT object type for fanspeed
Scaling [DPT_5.001]
Enable use of +/- object for Fan Speed
No
Enable use of bit-type Fan Speed objects (for Control)
No
Enable use of bit-type Fan Speed objects (for Status)
No
Enable use of Text object for Fan Speed
No
Enable use of Legacy_ object for Fan (compatible with old vers of XXACKNX1)
No

Figure 4.11 Default Fan Speed Configuration dialog

All the parameters in this section are related with the Fan Speed properties and communication objects.

4.4.1 Fan is accessible in Indoor unit

This parameter lets choose if the unit has Fan Speed control available or not.



Figure 4.12 Parameter detail

- If set to **"no"** all the parameters and communication objects for the Fan Speed will not be shown.
- If set to **"yes"** all the parameters and communication objects (if enabled in the parameters dialog) for the Fan Speed will be shown.

⚠ ***Important:*** *Read the documentation of your indoor unit to check if Fan Speed control is available.*

4.4.2 Available fanspeeds in Indoor Unit

This parameter lets choose how many fan speeds are available in the indoor unit.



Figure 4.13 Parameter detail

⚠ ***Important:*** *Read the documentation of your indoor unit to check how many fan speeds are available.*

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

4.4.3 Indoor unit has AUTO fan speed

This parameter lets choose if the indoor unit has Auto Fan Speed available or not.



Figure 4.14 Parameter detail

- If set to **"no"** all the parameters and communication objects for the Auto Fan Speed will not be shown.
- If set to **"yes"** a new parameter will appear. Find more information on section *2.4.6 Enable "Fan Speed Manual/Auto" objects.*



Figure 4.15 Parameter detail

⚠ ***Important:*** *Read the documentation of your indoor unit to check if Auto Fan Speed is available.*

4.4.4 DPT object type for fanspeed

With this parameter is possible to change de DPT for the *Control_ Fan Speed* and *Status_ Fan Speed* byte-type communication objects. Datapoints Scaling (DPT_5.001) and Enumerated (DPT_5.010) can be selected.

⚠ ***Important:*** *The communication objects shown in this section may be different depending on the number of fan speeds available, although they all share the same communication object number.*

- When **"Enumerated [DPT 5.010]"** is selected, *Control_ Fan Speed* and *Status_ Fan Speed* communication objects for this DPT will appear.


11: Control_ Fan Speed / 4 Speeds [DPT_5.010 - 1byte] - Speed values: 1,2,3,4
63: Status_ Fan Speed / 4 Speeds [DPT_5.010 - 1byte] - Speed Values: 1,2,3,4

The first fan speed will be selected if a **"1"** is sent to the *Control_* object. The second one will be selected sending a **"2"**; the third one (if available) will be selected sending a **"3"**; the fourth one (if available) will be selected sending a **"4"**.

The *Status_* object will always return the value for the fan speed selected.

⚠ ***Important:*** *If a **"0"** value is sent to the Control_ object, the minimum fan speed will be selected. If a value bigger than **"4"** is sent to the Control_ object, then the maximum fan speed will be selected.*

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

- When **"Scaling [DPT 5.001]"** is selected, *Control_ Fan Speed* and *Status_ Fan Speed* communication objects for this DPT will appear.


11: Control_ Fan Speed / 4 Speeds [DPT_5.001 - 1byte] - Thresholds:38%, 63% and 88%
63: Status_ Fan Speed / 4 Speeds [DPT_5.001 - 1byte] - 25%, 50%, 75% and 100%

The next table shows the range of values that can be sent through the *Control_* object and the value returned by the *Status_* object.

	Fan Speed 1	*Fan Speed 2*	*Fan Speed 3*	*Fan Speed 4*
*Control_*	0% - 74%	75% - 100%		
*Status_*	50%	100%		
*Control_*	0% - 49%	50% - 82%	83% - 100%	
*Status_*	33%	67%	100%	
*Control_*	0% - 37%	38% - 62%	63% - 87%	88% - 100%
*Status_*	25%	50%	75%	100%

⚠ ***Important:*** *Read the documentation of your indoor unit to check how many fan speeds are available.*

4.4.5 Enable use of +/- object for Fan Speed

This parameter shows/hides the *Control_ Fan Speed +/-* communication object which lets increase/decrease the indoor unit fan speed by using two different datapoint types.



- If set to **"no"** the object will not be shown.
- If set to **"yes"** the *Control_ Fan Speed +/-* object and a new parameter will appear.


Enable use of +/- object for Fan Speed
Yes
> DPT type for +/- Fan Speed object
0-Decrease / 1-Increase [DPT_1.007]
> Does +/- sequence include fan speed AUTO?
No
> Roll over Speed at upper/lower limit (when controlling with +/- obj)
Yes

Figure 4.16 Parameter detail

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

- DPT type for +/- Fan Speed Object

  This parameter lets choose between the datapoints **0-Up / 1-Down [DPT_1.008]** and **0-Decrease / 1-Increase [DPT_1.007]** for the *Control_ Fan Speed +/-* object.

- Does +/- sequence include fan speed AUTO?

  This parameter lets choose if AUTO function is included (**"yes"**) or not (**"no"**) in the sequence when using *Control_ Fan Speed +/-* object as shown in the discontinuous segment at the picture below.

- Roll-over Speed at upper/lower limit

  This parameter lets choose if roll-over will be enabled (**"yes"**) or disabled (**"no"**) for the *Control_ Fan Speed +/-* object.



- Up / Increase
- Down / Decrease
- * If Available

4.4.6 Enable "Fan Speed Manual/Auto" objects (for Control and Status)

This parameter shows/hides the bit-type *Control_ Fan Speed Manual/Auto* objects.



- If set to **"no"** the *Control_ Fan Speed Manual/Auto* communication objects will not be shown.
- If set to **"yes"** the *Control_ Fan Speed Manual/Auto* communication objects will appear.

4.4.7 Enable use of bit-type Fan Speed objects (for Control)

This parameter shows/hides the bit-type *Control_ Fan Speed* objects.


13: Control_ Fan Speed 1 [DPT_1.002 - 1bit] - 1-Set Fan Speed 1
14: Control_ Fan Speed 2 [DPT_1.002 - 1bit] - 1-Set Fan Speed 2
15: Control_ Fan Speed 3 [DPT_1.002 - 1bit] - 1-Set Fan Speed 3
16: Control_ Fan Speed 4 [DPT_1.002 - 1bit] - 1-Set Fan Speed 4

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

- If set to **"no"** the objects will not be shown.
- If set to **"yes"** the *Control_ Fan Speed* objects for Speed 1, Speed 2, Speed 3 (if available), and Speed 4 (if available) will appear. To activate a Fan Speed by using these objects a **"1"** value has to be sent.

4.4.8 Enable use of bit-type Fan Speed objects (for Status)

This parameter shows/hides the bit-type *Status_ Fan Speed* objects.

65: Status_ Fan Speed 1 [DPT_1.002 - 1bit] - 1-Fan in speed 1
66: Status_ Fan Speed 2 [DPT_1.002 - 1bit] - 1-Fan in speed 2
67: Status_ Fan Speed 3 [DPT_1.002 - 1bit] - 1-Fan in speed 3
68: Status_ Fan Speed 4 [DPT_1.002 - 1bit] - 1-Fan in speed 4

- If set to **"no"** the objects will not be shown.
- If set to **"yes"** the *Status_ Fan Speed* objects for Speed 1, Speed 2, Speed 3 (if available), and Speed 4 (if available) will appear. When a Fan Speed is enabled, a **"1"** value is returned through its bit-type object.

4.4.9 Enable use of Text object for Fan Speed

This parameter shows/hides the *Status_ Fan Speed Text* communication object.

69: Status_ Fan Speed Text [DPT_16.001 - 14byte] - ASCII String

- If set to **"no"** the object will not be shown.
- If set to **"yes"** the *Status_ Fan Speed Text* object will appear. Also, in the parameters, will be shown five text fields, one for each Fan Speed, that will let modify the text string displayed by the *Status_ Fan Speed Text* when changing a fan speed.

> String when fan speed is AUTO (if available)	AUTO
> String when fan speed is 1	SPEED 1
> String when fan speed is 2	SPEED 2
> String when fan speed is 3 (if available)	SPEED 3
> String when fan speed is 4 (if available)	SPEED 4

Figure 4.17 Parameter detail

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

4.4.10 Enable use of Legacy_ object for Fan Speed

This parameter shows/hides the *Legacy_ Fan Speed* communication object



- If set to **"no"** the communication object will not be shown.
- If set to **"yes"** the communication object will appear. This object lets change the indoor unit fan speed but it uses a different data type. It is used to maintain compatibility with old gateway models.

4.5 Vanes Up-Down Configuration dialog


Device: 1.1.1 ME AC Interface
General
Mode Configuration
Special Modes Configuration
Fan Speed Configuration
Vanes Up-Down Configuration
Temperature Configuration
Scene Configuration
Switch-Off Timeouts Configuratior
Binary Input 1 Configuration
Binary Input 2 Configuration
Binary Input 3 Configuration
Binary Input 4 Configuration
Indoor unit has U-D Vanes (see docum. for your indoor unit)
Yes
Available positions in Indoor Unit (see docum. for your indoor unit)
5
Indoor unit has AUTO Vanes U-D (see docum. for your indoor unit)
No
DPT object type for Vanes Up-Down
Enumerated [DPT_5.010]
Enable use of +/- object for Vanes U-D
No
Enable use of bit-type Vanes U-D objects (for Control)
No
Enable use of bit-type Vanes U-D objects (for Status)
No
Enable "Vanes U-D Swing" objects (for Control and Status)
No
Enable use of Text object for Vanes U-D
No
Enable use of Legacy_ object for Vanes (compatible with old vers of XXACKNX1)
No

Figure 4.18 Vanes Up-Down Configuration dialog

All the parameters in this section are related with the Vanes Up-Down properties and communication objects.

4.5.1 Indoor unit has U-D Vanes

This parameter lets choose if the unit has Up-Down Vanes available or not.



Figure 4.19 Parameter detail

- If set to **"no"** all the parameters and communication objects for the Up-Down Vanes will not be shown.
- If set to **"yes"** all the parameters and communication objects (if enabled in the parameters dialog) for the Up-Down Vanes will be shown.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

⚠ ***Important:*** *Read the documentation of your indoor unit to check if Up-Down Vanes are available.*

4.5.2 Available positions in Indoor Unit

This parameter lets choose how many vane positions are available in the indoor unit.



Figure 4.20 Parameter detail

⚠ ***Important:*** *Read the documentation of your indoor unit to check how many vane positions are available.*

4.5.3 Indoor unit has AUTO Vanes U-D

This parameter lets choose if the indoor unit has Auto Vanes U-D available or not.



Figure 4.21 Parameter detail

- If set to **"no"** all the parameters and communication objects for the Auto Vanes U-D will not be shown.
- If set to **"yes"** a new parameter will appear. Find more information on section *2.5.8 Enable "Vanes U-D Man/Auto" objects (for Control and Status).*



Figure 4.22 Parameter detail

⚠ ***Important:*** *Read the documentation of your indoor unit to check if Auto Vane Position is available.*

4.5.4 DPT object type for Vanes Up-Down

With this parameter is possible to change de DPT for the *Control_ Vanes U-D* and *Status_ Vanes U-D* byte-type communication objects. Datapoints Scaling (DPT_5.001) and Enumerated (DPT_5.010) can be selected.

⚠ ***Important:*** *The communication objects shown in this section may be different depending on the number of vanes position available, although they all share the same communication object number.*

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® *is a registered trademark of Intesis Software SL*

- When **"Enumerated [DPT 5.010]"** is selected, *Control_ Vanes U-D* and *Status_ Vanes U-D* communication objects for this DPT will appear.


18: Control_ Vanes U-D / 5 Pos [DPT_5.010 - 1byte] - Position values: 1,2,3,4,5
70: Status_ Vanes U-D / 5 pos [DPT_5.010 - 1byte] - Position values: 1,2,3,4,5

  To choose a vanes position, values from **"1"** to **"4"** (or **"5"** when available) can be sent to the *Control_* object. Each value will correspond to the position (i.e. Value **"3"** = Position 3).

  The *Status_* object will always return the value for the vane position selected.

  ⚠ ***Important:*** *If a **"0"** value is sent to the Control_ object, the Position 1 will be selected. If a value bigger than **"4"** (or **"5"** when available) is sent to the Control_ object, then the higher Position will be selected.*

- When **"Scaling [DPT 5.001]"** is selected, *Control_ Vane Up-Down* and *Status_ Vane Up-Down* communication objects for this DPT will appear.



  The next table shows the range of values that can be sent through the *Control_* object and the value returned by the *Status_* object.

	Vanes Pos.1	*Vanes Pos.2*	*Vanes Pos.3*	*Vanes Pos.4*	*Vanes Pos.5*
*Control_*	0% - 37%	38% - 62%	63% - 87%	88% - 100%	
*Status_*	25%	50%	75%	100%	
*Control_*	0% - 29%	30% - 49%	50% - 69%	70% - 89%	90% - 100%
*Status_*	20%	40%	60%	80%	100%

⚠ ***Important:*** *Read the documentation of your indoor unit to check how many vane positions are available.*

4.5.5 Enable use of +/- object for Vanes U-D

This parameter shows/hides the *Control_ Vane Up-Down +/-* communication object which lets change the indoor unit vane position by using two different datapoint types.



- If set to **"no"** the object will not be shown.
- If set to **"yes"** the *Control_ Vanes U-D +/-* object and a new parameter will appear.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL


Enable use of +/- object for Vanes U-D
Yes
> DPT type for +/- Vanes U-D object
0-Decrease / 1-Increase [DPT_1.007]
> Does +/- sequence include AUTO vanes Up-Down?
No
> Does +/- sequence include SWING vanes Up-Down?
No
> Rollover Vanes at upper/lower limit (when controlling with +/- obj)
Yes

Figure 4.23 Parameter detail

- DPT type for +/- Vane Up-Down obj

  This parameter lets choose between the datapoints **0-Up / 1-Down [DPT_1.008]** and **0-Decrease / 1-Increase [DPT_1.007]** for the *Control_ Vanes U-D +/-* object.

- Does +/- sequence include AUTO vanes Up-Down?

  This parameter lets choose if AUTO function is included (**"yes"**) or not (**"no"**) in the sequence when using *Control_ Vanes U-D +/-* object as shown in the discontinuous segment at the picture below.

- Does +/- sequence include SWING vanes Up-Down?

  This parameter lets choose if SWING function is included (**"yes"**) or not (**"no"**) in the sequence when using *Control_ Vanes U-D +/-* object as shown in the discontinuous segment at the picture below.

- Roll over Vanes at upper/lower limit

  This parameter lets choose if roll-over will be enabled (**"yes"**) or disabled (**"no"**) for the *Control_ Vanes U-D +/-* object.



- Up / Increase
- Down / Decrease
- * If Available

4.5.6 Enable use of bit-type Vane U-D objects (for Control)

This parameter shows/hides the bit-type *Control_ Vanes U-D* objects.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL


20: Control_ Vanes U-D Pos 1 [DPT_1.002 - 1bit] - 1-Set Position 1
21: Control_ Vanes U-D Pos 2 [DPT_1.002 - 1bit] - 1-Set Position 2
22: Control_ Vanes U-D Pos 3 [DPT_1.002 - 1bit] - 1-Set Position 3
23: Control_ Vanes U-D Pos 4 [DPT_1.002 - 1bit] - 1-Set Position 4
24: Control_ Vanes U-D Pos 5 [DPT_1.002 - 1bit] - 1-Set Position 5

- If set to **"no"** the objects will not be shown.
- If set to **"yes"** the *Control_ Vanes U-D* objects for each Position will appear. To activate a Vanes Position by using these objects, a **"1"** value has to be sent.

4.5.7 Enable use of bit-type Vane U-D objects (for Status)

This parameter shows/hides the bit-type *Status_ Vanes U-D* objects.


72: Status_ Vanes U-D Pos 1 [DPT_1.002 - 1bit] - 1-Vanes in Position 1
73: Status_ Vanes U-D Pos 2 [DPT_1.002 - 1bit] - 1-Vanes in Position 2
74: Status_ Vanes U-D Pos 3 [DPT_1.002 - 1bit] - 1-Vanes in Position 3
75: Status_ Vanes U-D Pos 4 [DPT_1.002 - 1bit] - 1-Vanes in Position 4
76: Status_ Vanes U-D Pos 5 [DPT_1.002 - 1bit] - 1-Vanes in Position 5

- If set to **"no"** the objects will not be shown.
- If set to **"yes"** the *Status_ Vanes U-D* objects for each Position will appear. When a Vanes Position is enabled, a **"1"** value is returned through its bit-type object.

4.5.8 Enable "Vanes U-D Man/Auto" objects (for Control and Status)

This parameter shows/hides the *Control_ Vanes U-D Man/Auto* and *Status_ Vanes U-D Man/Auto* communication objects.



- If set to **"no"** the objects will not be shown.
- If set to **"yes"** the *Control_ Vanes U-D Man/Auto* and *Status_ Vanes U-D Man/Auto* objects will appear.
    - When a **"1"** value is sent to the *Control_* communication object, Vanes Up-Down will be in Auto mode, and the *Status_* object will return this value.
    - When a **"0"** value is sent to the *Control_* communication object, Vanes Up-Down will be in Manual mode and the first position will be enabled. The *Status_* object will return this value.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

⚠ ***Important:*** *When in Auto Mode the indoor unit will choose the most appropriate vane up-down position, but this will be shown neither in KNX nor in the remote controller.*

4.5.9 Enable "Vanes U-D Swing" objects (for Control and Status)

This parameter shows/hides the *Control_ Vanes U-D Swing* and *Status_ Vanes U-D Swingo* communication objects.

25: Control_ Vanes U-D Swing [DPT_1.002 - 1bit] - 0-Off;1-Swing
77: Status_ Vanes U-D Swing [DPT_1.002 - 1bit] - 0-Off;1-Swing

- If set to **"no"** the objects will not be shown.
- If set to **"yes"** the *Control_ Vanes U-D Swing* and *Status_ Vanes U-D Swing* objects will appear.
    - When a **"1"** value is sent to the *Control_* communication object, Vanes Up-Down will be in Auto mode, and the *Status_* object will return this value.
    - When a **"0"** value is sent to the *Control_* communication object, Vanes Up-Down will be in Manual mode and the first position will be enabled. The *Status_* object will return this value.

4.5.10 Enable use of Text object for Vane U-D

This parameter shows/hides the *Status_ Vanes U-D Text* communication object.

78: Status_ Vanes U-D Text [DPT_16.001 - 14byte] - ASCII String

- If set to **"no"** the object will not be shown.
- If set to **"yes"** the *Status_ Vanes U-D Text* object will appear. Also, in the parameters will be shown seven text fields, five for the Vane Position and one for the Auto function and another one for the Swing function, that will let modify the text string displayed by the *Status_ Vanes U-D Text* when changing a vane position.

> String when vanes U-D in AUTO (if available)	U-D AUTO
> String when vanes U-D in POS 1	U-D POS 1
> String when vanes U-D in POS 2	U-D POS 2
> String when vanes U-D in POS 3	U-D POS 3
> String when vanes U-D in POS 4	U-D POS 4
> String when vanes U-D in POS 5 (if available)	U-D POS 5
> String when vanes U-D in SWING	U-D SWING

Figure 4.24 Parameter detail

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

4.5.11 Enable use of Legacy_ object for Vanes

This parameter shows/hides the *Legacy_ Vanes* communication object



- If set to **"no"** the communication object will not be shown.
- If set to **"yes"** the communication object will appear. This object lets change the indoor unit vanes behavior but it uses a different data type. It is used to maintain compatibility with old gateway models.

4.6 Temperature Configuration dialog


Device: 1.1.1 ME AC Interface
General
Mode Configuration
Special Modes Configuration
Fan Speed Configuration
Vanes Up-Down Configuration
Temperature Configuration
Scene Configuration
Switch-Off Timeouts Configuration
Binary Input 1 Configuration
Binary Input 2 Configuration
Binary Input 3 Configuration
Binary Input 4 Configuration
Periodic sending of "Status_ AC Setp" (in seconds;0=No periodic sending)
0
Transmission of "Status_ AC Return Temp"
Only cyclically
> "Status_ AC Return Temp" periodic sending time (in sec)
180
Enable use of +/- obj for Setpoint Temp
No
Enable limits on Control_ Setpoint obj
No
Ambient temp. ref. is provided from KNX (carefully read User Guide if enabled)
No

Figure 4.25 Default Temperature Configuration dialog

All the parameters in this section are related with the Temperature properties and communication objects.

4.6.1 Periodic sending of "Status_ AC Setp"

This parameter lets change the interval of time (in seconds, from 0 to 255) at the end of which the AC setpoint temperature is sent to the KNX bus. For a **"0"** value, the AC setpoint temperature will ONLY be sent on change. The AC setpoint temperature is sent through the communication object *Status_ AC Setpoint Temp.*



Figure 4.26 Parameter detail

⚠ ***Important:*** *In case the ambient temperature is provided from KNX, the setpoint temperature returned from this object, will be the one resulting from the formula shown in the section "2.6.5 Ambient temp. ref. is provided from KNX".*

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

4.6.2 Transmission of "Status_ AC Return Temp"

This parameter lets to you choose if the AC return temperature will be sent **"only cyclically"**, **"only on change"** or **"cyclically and on change"**. The AC return temperature is sent through the communication object *Status_ AC Return Temp.*


80: Status_ AC Return Temperature [DPT_9.001 - 2byte] - (ºC)
Transmission of "Status_ AC Return Temp"
Cyclically and on change
> "Status_ AC Return Temp" periodic sending time (in sec)
180

Figure 4.27 Parameter detail

- "Status_ AC Return Temp" periodic sending time (in sec)

  This parameter will only be available for the **"only cyclically"** and **"cyclically and on change"** options, and let's you change the interval of time (in seconds, from 1 to 255) at the end of which the AC return temperature is sent to the KNX bus.

4.6.3 Enable use of +/- object for Setpoint Temp

This parameter shows/hides the *Control_ Setpoint Temp +/-* communication object which lets change the indoor unit setpoint temperature by using two different datapoint types.



- If set to **"no"** the object will not be shown.
- If set to **"yes"** the *Control_ Setpoint Temp +/-* object and a new parameter will appear.



Figure 4.28 Parameter detail

- DPT type for +/- Setp Temp object

  This parameter lets choose between the datapoints **0-Up / 1-Down [DPT_1.008]** and **0-Decrease / 1-Increase [DPT_1.007]** for the *Control_ Setpoint Temp +/-* object.

  (Lower limit) **19ºC** ⇄ 20ºC ⇄ … ⇄ 27ºC ⇄ **28ºC** (Upper limit)

  - Up / Increase
  - Down / Decrease

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

4.6.4 Enable limits on Control_ Setpoint obj

This parameter enables to define temperature limits for the *Control_ Setpoint Temperature* object.



Figure 4.27 Parameter detail

- If set to **"no"** the setpoint temperature limits for the *Control_ Setpoint Temperature* object will be the default: 19ºC for the lower limit and 28ºC for the upper limit.
- If set to **"yes"** it is possible to define temperature limits for the *Control_ Setpoint Temperature* object.
  - Control_ Set Temp Lower limit (ºC)

    This parameter lets to define the lower limit for the setpoint temperature.

  - Control_ Set Temp Upper limit (ºC)

    This parameter lets to define the upper limit for the setpoint temperature.

⚠ ***Important:*** *If a setpoint temperature above the upper defined limit (or below the lower defined limit) is sent through the Control_ Setpoint Temperature object, it will be ALWAYS applied the limit defined.*

⚠ ***Important:*** *When limits are enabled, any setpoint temperature sent to the AC (even through scenes, special modes, etc.) will be limited.*

4.6.5 Ambient temp. ref. is provided from KNX

This parameter shows/hides the *Control_ Ambient Temperature* communication object which lets use an ambient temperature reference provided by a KNX device.



- If set to **"no"** the object will not be shown.
- If set to **"yes"** the *Control_ Ambient Temperature* object will appear. Meant to be enabled when you want the temperature provided by a KNX sensor to be the reference ambient temperature for the air conditioner. Then, the following formula applies for calculation of real *Control_ Setpoint Temperature* sent to the AC unit:

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

"AC Setp. Temp" = "AC Ret. Temp" - ("KNX Amb. Temp." - "KNX Setp. Temp")

- AC Setp. Temp: AC indoor unit setpoint temperature
- AC Ret. Temp: AC indoor unit return temperature
- KNX Amb. Temp.: Ambient temperature provided from KNX
- KNX Setp. Temp: Setpoint temperature provided from KNX

As an example, consider the following situation:

User wants: **19ºC** ("KNX Setp. Temp.")
User sensor (a KNX sensor) reads: **21ºC** ("KNX Amb Temp.")
Ambient temp. read by Mitsubishi system is: **24ºC** ("AC Ret. Temp")

In this example, the final setpoint temperature that DK-RC-KNX-1 will send out to the indoor unit (shown in "Setp. Temp.") will become 24ºC – (21ºC - 19ºC) = **22ºC**. This is the setpoint that will actually be requested to Mitsubishi Electric unit.

This formula will be applied as soon as the *Control_ Setpoint Temperature* and *Control_ Ambient Temperature* objects are written at least once from the KNX installation. After that, they are kept always consistent.

Note that this formula will always drive the AC indoor unit demand in the *right* direction, regardless of the operation mode (Heat, Cool or Auto).

4.7 Scene Configuration dialog



Figure 4.28 Parameter detail

All the parameters in this section are related with the Scene properties and communication objects. A scene contains values of: On/Off, Mode, Fan speed, Vane position, Setpoint Temperature and Remote Controller Disablement.

4.7.1 Enable use of scenes

This parameter shows/hides the scene configuration parameters and communication objects.



© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

Figure 4.29 Parameter detail

- If set to **"no"** the scene parameters and communication objects will not be shown.
- If set to **"yes"** the scene parameters and communication objects will be shown. To execute a scene through the byte-type object, a value from **"0"** to **"4"** has to be sent, correponding each one to a different scene (i.e. "0" = Scene 1;… "4" = Scene 5).

4.7.2 Scenes can be stored from KNX bus

This parameter shows/hides the *Control_ Save/Exec Scene* and all the *Control_ Store Scene* (if enabled) communication objects.


39: Control_ Save/Exec Scene [DPT_18.001 - 1byte] - 0..4-Exec1-5;128..132-Save1-5
40: Control_ Store Scene 1 [DPT_1.002 - 1bit] - 1-Store Scene 1
41: Control_ Store Scene 2 [DPT_1.002 - 1bit] - 1-Store Scene 2
42: Control_ Store Scene 3 [DPT_1.002 - 1bit] - 1-Store Scene 3
43: Control_ Store Scene 4 [DPT_1.002 - 1bit] - 1-Store Scene 4
44: Control_ Store Scene 5 [DPT_1.002 - 1bit] - 1-Store Scene 5

- If set to **"no"** the communication objects will not be shown.
- If set to **"yes"** the communication objects and a new parameter will appear. To store a scene through the byte-type object, a value from **"128"** to **"132"** has to be sent to the object, correponding each one to a different scene (i.e. "128" = Scene 1;… "132" = Scene 5).



Figure 4.30 Parameter detail

➢ Enable use of bit objects for storing scenes (from bus)

If set to **"no"** the objects will not be shown.

If set to **"yes"** the *Control_ Store Scene* objects for storing scenes will appear. To store a scene by using these objects, a **"1"** value has to be sent to the scene's object we want to store (i.e. to store scene 4, a "1" has to be sent to the *Control_ Store Scene 4* object).

4.7.3 Enable use of bit objects for scene execution

This parameter shows/hides the *Control_ Execute Scene* bit-type communication objects.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL


45: Control_ Execute Scene 1 [DPT_1.002 - 1bit] - 1-Execute Scene 1
46: Control_ Execute Scene 2 [DPT_1.002 - 1bit] - 1-Execute Scene 2
47: Control_ Execute Scene 3 [DPT_1.002 - 1bit] - 1-Execute Scene 3
48: Control_ Execute Scene 4 [DPT_1.002 - 1bit] - 1-Execute Scene 4
49: Control_ Execute Scene5 [DPT_1.002 - 1bit] - 1-Execute Scene 5
Enable use of bit objects for scene execution
yes

Figure 4.31 Parameter detail

- If set to **"no"** the communication objects will not be shown.
- If set to **"yes"** the communication objects will appear. To execute a scene by using these objects, a **"1"** value has to be sent to the scene's object we want to execute (i.e. to execute scene 4, a "1" has to be sent to the *Control_ Execute Scene 4* object).

4.7.4 Scene "x" preset

This parameter lets define a preset for a scene (the following description is valid for all the scenes).



Figure 4.32 Parameter detail

- If set to **"no"** the preset for the scene "x" will be disabled.
- If set to **"yes"** the preset will be enabled. When a scene is executed the values configured in the preset will be aplied.

⚠ ***Important:*** *If a scene's preset is enabled, will not be possible to modify (store) the scene from the KNX bus.*


> Scene 1 / Value for On-Off
ON
> Scene 1 / Value for Mode
COOL
> Scene 1 / Value for Fan Speed (if available)
FAN SPEED 3 (if available)
> Scene 1 / Value for Vanes U-D (if available)
VANES U-D POS 5 (if available)
> Scene 1 / Value for Setpoint Temp
22.0 °C
> Scene 1 / Value for Remote Lock
(unchanged)

Figure 4.33 Parameter detail

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

- Scene "x" / Value for On-Off

  This parameter lets choose the power of the indoor unit when the scene is executed. The following options are available: **"ON", "OFF"** or **"(unchanged)"**.

- Scene "x" / Value for Mode

  This parameter lets choose the mode of the indoor unit when the scene is executed. The following options are available: **"AUTO"**, **"HEAT", "COOL"**, **"FAN (if available)"**, **"DRY"**, or **"(unchanged)"**.

- Scene "x" / Value for Fan Speed (if available)

  This parameter lets choose the fan speed of the indoor unit when the scene is executed. The following options are available: **"FAN SPEED AUTO (if available)"**, **"FAN SPEED 1"**, **"FAN SPEED 2"**, **"FAN SPEED 3 (if available)"**, **"FAN SPEED 4 (if available)"**, or **"(unchanged)"**.

- Scene "x" / Value for Vane U-D (if available)

  This parameter lets choose the vane position of the indoor unit when the scene is executed. The following options are available: **"VANES U-D AUTO (if available)", "VANES U-D POS 1"**, **"VANES U-D POS 2"**, **"VANES U-D POS 3"**, **"VANES U-D POS 4", "VANES U-D POS 5 (if available)", "VANES U-D SWING"** or **"(unchanged)"**.

- Scene "x" / Value for Setp Temp (ºC)

  This parameter lets choose the setpoint temperature of the indoor unit when the scene is executed. The following options are available: from **"19ºC"** to **"28ºC"** (both included), or **"(unchanged)"**.

- Scene "x" / Value for Remote Lock

  This parameter lets choose the remote controller status of the indoor unit when the scene is executed. The following options are available: **"locked"**, **"unlocked"**, or **"(unchanged)"**.

⚠ ***Important:*** *If any preset value is configured as* ***"(unchanged)"****, the execution of this scene will not change current status of this feature in the AC unit.*

⚠ ***Important:*** *When a scene is executed, Status_ Current Scene object shows the number of this scene. Any change in previous items does Status_ Current Scene show* ***"No Scene"****. Only changes on items marked as* ***"(unchanged)"*** *will not disable current scene.*

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

4.8 Switch-Off Timeouts Configuration dialog



Figure 4.34 Default Switch-Off Timeouts Configuration dialog

All the parameters in this section are related with the timeout properties and communication objects.

4.8.1 Enable use of Open Window / Switch off timeout function

This parameter shows/hides the *Control_ Switch Off Timeout* communication object which lets Start/Stop a timeout to switch off the indoor unit.



- If set to **"no"** the object will not be shown.

- If set to **"yes"** the *Control_ Switch Off Timeout* object and new parameters will appear. If a **"1"** value is sent to this object, and the indoor unit is already turned on, the switch-off timeout will begin. If a **"0"** value is sent to this object, the switch-off timeout will stop.


Enable use of Open Window / Switch off timeout function
yes
> AC switch-off timeout (min)
2
> DPT for Window / Switch-off timeout
0-Open / 1-Closed Window [DPT_1.009]
> Reload last On/Off val once window is closed
no
> Disallow On/Off operation while window is Open
yes

Figure 4.35 Parameter detail

➢ AC switch-off timeout (min)

This parameter lets select how much time (in minutes) to wait before switching off the indoor unit.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

- DPT for Window / Switch-off timeout

  This parameter lets choose between the datapoints **0-Open / 1-Closed Window [DPT_1.009]** and **0-Stop / 1-Start Timeout [DPT_1.010]** for the *Control_ Switch Off Timeout*.

- Disallow On/Off operation while window is Open

  If set to **"no"**, On/Off commands while the window is open will be accepted.

  - If a **"1"** value is sent to the *Control_ Switch Off Timeout* object the switch-off timeout period will begin again.
  - If a **"0"** value is sent to the *Control_ Switch Off Timeout* object, no action will be performed.

  If set to **"yes"**, On/Off commands, while the window is open, will be saved (but not applied). These commands will be used in the next parameter if set to **"yes"**.

- Reload last On/Off val once window is closed?

  If set to **"no"**, once the switch-off timeout is stopped, any value will be reloaded.

  If set to **"yes"**, once the switch-off timeout is stopped, the last On/Off value sent will be reloaded.

  - If a **"1"** value is sent to the *Control_ Switch Off Timeout* object after the timeout period, the indoor unit will **turn on**.
  - If a **"0"** value is sent to the *Control_ Switch Off Timeout* after the timeout period, no action will be performed.

4.8.2 Enable use of Occupancy function

This parameter shows/hides the *Control_ Occupancy* communication object which lets apply different parameters to the indoor unit depending on the presence/no presence in the room.



- If set to **"no"** the object will not be shown.
- If set to **"yes"** the *Control_ Occupancy* object and new parameters will appear. If a **"1"** value is sent to this object (no room occupancy), the timeout will begin. If a **"0"** value is sent to this object, the timeout will stop.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL



Figure 4.36 Parameter detail

- Timeout to apply action (minutes)

  This parameter lets choose how much time to wait (in minutes) before executing the action specified in the next parameter ("Action after timeout elapsed").

- Action after timeout elapsed

  When **Switch-Off** is selected, once the timeout has elapsed, the indoor unit will be turned off.

  When **Apply Preset Delta** is selected, once the timeout has elapsed, a delta temperature will be applied in order to save energy (decreasing the setpoint when in Heat mode, or increasing the setpoint when in Cool mode). Also new parameters will appear.



Figure 4.37 Parameter detail

  - Temp delta decrease (HEAT) or increase (COOL) (ºC)

    This parameter lets configure the delta temperature (increase or decrease) that will be applied when the timeout has elapsed.

    ⚠ ***Important:*** *When there is occupancy again after the application of a delta, the same delta will be applied inversely. (i.e. In a room with AC in cool mode and 25ºC setpoint temperature, a* ***+2ºC*** *delta is applied after the occupancy timeout, setting the setpoint at 27ºC because there is no occupancy in the room. If the setpoint is raised to 29ºC during that period, when the room is occupied again, a* ***-2ºC*** *delta will be applied and the final setpoint temperature will then be 27ºC).*

  - Enable secondary timeout

    If set to **"no"** nothing will be applied.

    If set to **"yes"**, a new timeout will be enabled and two new parameters will appear.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL



Figure 4.38 Parameter detail

- Timeout to apply action (minutes)

  This parameter lets choose how much time to wait (in minutes) before executing the action specified in the next parameter ("Action after timeout elapsed").

- Action after timeout elapsed

  When **Switch-Off** is selected, once the timeouthas elapsed, the indoor unit will turn off.

  When **Apply Preset Delta** is selected, once the timeout configured is extinguished, a delta temperature will be applied (decreasing the setpoint when in Heat mode, or increasing the setpoint when in Cool mode). Also new parameters will appear.

  - Temp delta decrease (HEAT) or increase (COOL) (ºC)

    This parameter lets configure the delta temperature that will be applied when the timeout is extinguished.

    ⚠ ***Important:*** *When there is occupancy again after the application of a delta, the same delta will be applied inversely as explained above.*

- Disallow On/Off operation while not Occupied

  If set to **"no"**, On/Off commands while the window is open will be accepted.
  - If a **"1"** value is sent to the *Control_ Occupancy* object the switch-off timeout period will begin again.
  - If a **"0"** value is sent to the *Control_ Occupancy* object, no action will be performed.

  If set to **"yes"**, On/Off commands while not occupied will be saved (but not applied). These commands will be used in the next parameter if set to **"yes"**.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® *is a registered trademark of Intesis Software SL*



Figure 4.39 Parameter detail

➢ Reload last On/Off value when Occupied

If set to **"no"**, once the switch-off timeout has elapsed, any value will be reloaded.

If set to **"yes"**, once the switch-off timeout has elapsed, the last On/Off value will be reloaded.

- If a **"1"** value is sent to the *Control_ Occupancy* object after the timeout period, the indoor unit will **turn on**.
- If a **"0"** value is sent to the *Control_ Occupancy* after the timeout period no action will be performed.

4.8.3 Enable use of SLEEP timeout

This parameter shows/hides the *Control_ Sleep Timeout* communication object which lets start a timeout to automatically turn off the indoor unit.



- If set to **"no"** the object will not be shown.
- If set to **"yes"** the *Control_ Sleep Timeout* object and a new parameter will appear. If a **"1"** value is sent to this object the switch-off timeout will begin. If a **"0"** value is sent to this object, the switch-off timeout will stop.



Figure 4.40 Parameter detail

➢ Timeout to apply action (minutes)

This parameter lets select how much time (in minutes) to wait before switching off the AC unit.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

4.9 Binary Input "x" Configuration dialog



Figure 4.41 Binary Input Configuration dialog

All the parameters in this section are related with the binary inputs properties and communication objects.

4.9.1 Enable use of Input "x"

This parameter enables the use of the Input "x" and shows/hides the *Status_ Inx* communication object(s) which will act as configured in the "Function" parameter.


90: Status_ In1 - Switching [DPT_1.001 - 1bit] - 0-Off;1-On
92: Status_ In2 - Switching [DPT_1.001 - 1bit] - 0-Off;1-On
94: Status_ In3 - Switching [DPT_1.001 - 1bit] - 0-Off;1-On
96: Status_ In4 - Switching [DPT_1.001 - 1bit] - 0-Off;1-On

- If set to **"no"** the objects will not be shown.
- If set to **"yes"** the *Status_ Inx* object(s) and new parameters will appear.

4.9.2 Contact type

This parameter lets choose the behavior that will have the binary input depending on if the contact is normally open or normally closed.

- There are two possible options to configure the contact type: **"NO: Normally Open"** and **"NC: Normally Closed"**.

4.9.3 Debounce time

This parameter lets choose a debounce time (in milliseconds) that will be applied to the contact.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

4.9.4 Disabling function

This parameter shows/hides the *Control_ Disable Input x* communication object which will let disable/enable the input x.



- If set to **"no"** any object will be shown.
- When **"DPT 1.003: 0-Disable; 1-Enable"** is selected, the input can be disabled using the value **"0"** and enabled using the value **"1"**.
- When **"DPT 1.002: 0-Enable; 1-Disable"** is selected, the input can be disabled using the value **"1"** and enabled using the value **"0"**.

4.9.5 Function

This parameter lets choose the function that will have the binary input. There are 7 different functions available: Switching, Dimming, Shutter/Blind, Value, Execute Scene (internal), Occupancy (internal) and Window Contact (internal).

- When **"Switching"** is selected the communication object and new parameters for the Input "x" will appear as shown below.



Figure 4.42 Parameter detail

➢ Send telegram after bus recovery

This parameter lets select if the Binary Input "x" will send a telegram, or not, after a bus recovery, and the type of telegram sent (if enabled).

- When **"No action"** is selected, no telegram will be sent after a bus recovery.
- When **"Current status"** is selected, the binary input will send a telegram with its current status after a bus recovery. Also a new parameter will appear (see below).

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

- When **"On"** is selected, the binary input will send a telegram with a **"1"** value after a bus recovery. Also a new parameter will appear (see below).
- When **"Off"** is selected, the binary input will send a telegram with a **"0"** value after a bus recovery. Also a new parameter will appear (see below).



Figure 4.43 Parameter detail

➢ Sending delay after a bus recovery (seconds)

This parameter lets configure a delay (in seconds) that will be applied after a bus recovery and, after which, a telegram will be sent.

➢ Value on rising edge

This parameter lets select the value that the Binary Input "x" will send on a rising edge (contact activated).

- When **"On"** is selected, the binary input will always send telegrams with a **"1"** value.
- When **"Off"** is selected, the binary input will always send telegrams with a **"0"** value.
- When **"Toggle (On/Off)"** is selected, the binary input will send a **"1"** value after a **"0"** value and viceversa.
- When **"No action"** is selected, the binary input will not perform any action.

➢ Value on falling edge

This parameter lets select the value that the Binary Input "x" will send on a falling edge (contact deactivated).

- When **"On"** is selected, the binary input will always send telegrams with a **"1"** value.
- When **"Off"** is selected, the binary input will always send telegrams with a **"0"** value.
- When **"Toggle (On/Off)"** is selected, the binary input will send a **"1"** value after a **"0"** value and viceversa.
- When **"No action"** is selected, the binary input will not perform any action.

➢ Cyclical sending

This parameter lets enable/disable cyclical sending when a determined condition is met.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

- When **"When output value is On"** is selected, everytime a **"1"** value is sent, it will be sent cyclically. Also a new parameter will appear (see below).
- When **"When output value is Off"** is selected, everytime a **"0"** value is sent, it will be sent cyclically. Also a new parameter will appear (see below).
- When **"Always"** is selected, the binary input will send any value cyclically. Also a new parameter will appear (see below).
- When **"Never"** is selected, cyclical sending will be disabled.

➢ Period for cyclical sending (seconds)

This parameter lets configure a time (in seconds) for the cyclical sending.



Figure 4.44 Parameter detail

○ When **"Dimming"** is selected the communication objects and new parameters for the Input "x" will appear as shown below.


92: Status_ In2 - Dimming - On/Off [DPT_1.001 - 1bit] - 0-Off;1-On
93: Status_ In2 - Dimming - Step(%) [DPT_3.007 - 4bit] - Dimming step
> Function
Dimming
> Send telegram after bus recovery
No action
> Mode for short (long) operation
Toggle: On/Off (increase/decrease)
> Increasing step
+ 100 %
> Decreasing step
- 100 %
> Short/long operation limit (x100ms)
10
> Cyclical sending period (x100ms) (0-No cyclical sending)
0

Figure 4.45 Parameter detail

➢ Send telegram after bus recovery

This parameter lets select if the Binary Input "x" will send a telegram, or not, after a bus recovery, and the type of telegram sent (if enabled).

- When **"No action"** is selected, no telegram will be sent after a bus recovery.
- When **"On"** is selected, the binary input will send a telegram with a **"1"** value after a bus recovery. Also a new parameter will appear (see below).
- When **"Off"** is selected, the binary input will send a telegram with a **"0"** value after a bus recovery. Also a new parameter will appear (see below).

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL



Figure 4.46 Parameter detail

- Sending delay after a bus recovery (seconds)

  This parameter lets configure a delay (in seconds) that will be applied after a bus recovery and, after which, a telegram will be sent.

- Mode for short (long) operation

  This parameter lets select the value that the Binary Input "x" will send on a rising edge (contact activated), for a short and a long operation.

  - When **"On (increase)"** is selected, the binary input will always send telegrams with a **"1"** value for a short operation, and an **"increase step"** for a long operation.
  - When **"Off (decrease)"** is selected, the binary input will always send telegrams with a **"0"** value for a short operation, and an **"decrease step"** for a long operation.
  - When **"Toggle: On/Off (increase/decrease)"** is selected:
    - For the short operation the binary input will send a **"1"** value after a **"0"** value and viceversa.
    - For the long operation the binary input will send an **"increase step"** after a **"decrease step"** and viceversa.

⚠ ***Important:*** *Note that the first long operation in toggle depends on the last short operation, meaning that after a **"1"** value will be sent a **"decrease step"** and after a **"0"** value will be sent an **"increase step"**.*

⚠ ***Important:*** *The time period between a short and a long operation is defined in the parameter "Short/long operation limit (x100ms)".*

- Increasing step

  This parameter lets select the increasing step value (in %) that will be sent for a long operation.

- Decreasing step

  This parameter lets select the decreasing step value (in %) that will be sent for a long operation.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

➢ Short/long operation limit (x100ms)

This parameter lets introduce the time period difference for the short and the long operation.

➢ Cycl. send. period in long oper. (x100ms)

This parameter lets configure a time (in seconds) for the cyclical sending of a long operation.

- When **"Shutter/Blind"** is selected the communication objects and new parameters for the Input "x" will appear as shown below.


94: Status_ In3 - Shut/Blind - Step [DPT_1.023 - 1bit] - 0-Step Up;1-Step Down
95: Status_ In3 - Shut/Blind - Move [DPT_1.023 - 1bit] - 0-Move Up;1-Move Down
> Function
Shutter/Blind
> Send telegram after bus recovery
No action
> Operation
Toggle (Up/Down)
> Method
Step-Move-Step
> Short/long operation limit (x100ms)
10
> Vanes adjustment time (x100ms)
10

Figure 4.47 Parameter detail

➢ Send telegram after bus recovery

This parameter lets select if the Binary Input "x" will send a telegram, or not, after a bus recovery and the type of telegram sent (if enabled).

- When **"No action"** is selected, no telegram will be sent after a bus recovery.
- When **"Move Up"** is selected, the binary input will send a telegram with a **"0"** value after a bus recovery. Also a new parameter will appear (see below).
- When **"Move Down"** is selected, the binary input will send a telegram with a **"1"** value after a bus recovery. Also a new parameter will appear (see below).



Figure 4.48 Parameter detail

➢ Sending delay after a bus recovery (seconds)

This parameter lets configure a delay (in seconds) that will be applied after a bus recovery and, after which, a telegram will be sent.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

➢ Operation

This parameter lets select the value that the Binary Input "x" will send on a rising edge (contact activated).

- When **"Up"** is selected, the binary input will always send telegrams with a **"0"**.
- When **"Down"** is selected, the binary input will always send telegrams with a **"1"** value.
- When **"Toggle (Up/Down)"** is selected the binary input will send a **"0"** value after a **"1"** value and viceversa.

➢ Method

This parameter lets select the working method for the shutter/blind.

- When **"Step-Move-Step"** is selected: On a rising edge (contact activated) a step/stop telegram will be sent and will begin a time called **T1**. If a falling edge occurs (contact deactivated) during the **T1**, no action will be performed.

  If the rising edge is maintained longer than **T1**, a move telegram will be sent and will start a time called **T2**. If a falling edge occurs during the **T2**, a step/stop telegram will be sent. If a falling edge occurs after **T2** no action will be performed.

- When **"Move-Step"** is selected: On a rising edge a move telegram will be sent and will begin the **T2** time. If a falling edge occurs during the **T2**, a step/stop telegram will be sent. If a falling edge occurs after **T2** no action will be performed.

⚠ ***Important:*** *The **T1** time have to be defined in the "Short/long operation limit (x100ms)" parameter. Also the **T2** time have to be defined in the "Vanes adjustment time (x100ms)" parameter.*

➢ Short/long operation limit (x100ms)

This parameter lets introduce the time period difference for the short and the long operation (T1 time).

➢ Vanes adjustment time (x100ms)

This parameter lets introduce the time period for the vanes adjustment/blind movement (T2 time).

- When **"Value"** is selected the communication objects and new parameters for the Input "x" will appear as shown below.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL



Figure 4.49 Parameter detail

➢ Send telegram after bus recovery

This parameter lets select if the Binary Input "x" will send a telegram, or not, after a bus recovery and the type of telegram sent (if enabled).

- When **"No action"** is selected, no telegram will be sent after a bus recovery.
- When **"Fixed value"** is selected, the binary input will send a telegram with the same value configured in the "Value on rising edge" parameter. Also a new parameter will appear (see below).



Figure 4.50 Parameter detail

➢ Sending delay after a bus recovery (seconds)

This parameter lets configure a delay (in seconds) that will be applied after a bus recovery and, after which, a telegram will be sent.

➢ DPT to be sent

This parameter lets select the DPT type for the value that will be defined in the next parameter. This value will be sent on a rising edge (contact activated).

Figure 4.51 Parameter detail

➢ Value on rising edge (when contact activated)

This parameter lets define a value for the DTP type configured in the "DPT to be sent" parameter. This value will be sent on a rising edge (contact activated).

- When **"Execute Scene (internal)"** is selected, the binary input "x" will activate the scene defined in the next parameter, on a rising edge (contact activated).

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL



Figure 4.52 Parameter detail

- Scene when contact is activated

  This parameter lets choose the scene that will be activated on a rising edge. This scene MUST be defined in the "Scene Configuration" dialog as a preset.

- When **"Occupancy (internal)"** is selected, the binary input "x" will have the same behavior as configured in the parameter "Enable use of Occupancy function" inside the "Switch-Off Timeouts Configuration" dialog.

Figure 4.53 Parameter detail

- When **"Window Contact (internal)"** is selected, the binary input "x" will have the same behavior as configured in the parameter "Enable use of Open Window / Switch off timeout function" inside the "Switch-Off Timeouts Configuration" dialog.

Figure 4.54 Parameter detail

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

5. Specifications

Envelope	ABS (UL 94 HB). 2,5 mm thickness
Dimensions	59 x 45 x 21 mm
Weight	35g
Colour	Light Grey
Power supply	29V DC, 7mA Supplied through KNX bus.
LED indicators	1 x KNX programming.
Push buttons	1 x KNX programming.
Binary inputs	4 x Potential-free binary inputs. Signal cable length: 5m uschielded, may be extended up to 20m with twisted. Compliant with the following standards: IEC61000-4-2 : level 4 - 15kV (air discharge) - 8kV (contact discharge) MIL STD 883E-Method 3015-7 : class3B
Configuration	Configuration with ETS.
Operating Temperature	From -25ºC to 85ºC
Storage Temperature	From -40ºC to 85ºC
Isolation Voltage	4000V
RoHS conformity	Compliant with RoHS directive (2002/95/CE).
Certifications	CE conformity to EMC directive (2004/108/EC) and Low-voltage directive (2006/95/EC) EN 61000-6-2; EN 61000-6-3; EN 60950-1; EN 50491-3; EN 50090-2-2; EN 50428; EN 60669-1; EN 60669-2-1



6. AC Unit Types compatibility.

A list of Mitsubishi Electric indoor unit models compatible with ME-AC-KNX-1i and their available features can be found in:

http://www.intesis.com/pdf/IntesisBox_ME-AC-xxx-1_AC_Compatibility.pdf

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

7. Error Codes

Code (In Hexadecimal)	Description
-1	Communication error between the ME-AC-KNX-1i gateway and the AC unit
0	No active error
0001	Communication error with the AC unit
1102	Discharge Temperature high
1108	Internal thermostat detector working (49C)
1110	Outdoor unit fail
1300	Pressure low
1302	Pressure high (High pressure probe working 63H)
1503	Protection against freeze or battery high temperature
1504	Protection against freeze or battery high temperature
1504	Over heating protection
1509	High pressure error (ball valve closed)
1520	Super heating anomaly due to low temp. of discharge. (TH4)
2500	Erroneous operation of drain pump
2502	Erroneous operation of drain pump
2503	Drain sensor anomaly (DS)
4030	Serial transmission error
4100	Compressor pause due to excess of current (initial block)
4101	Compressor pause due to excess of current (overload)
4102	Phase detection opened
4103	Anti-phase detection
4108	Phase opened in phase L2 or connector 51CM opened
4118	Error in the anti-phase detector (electronic board)
4124	Connector 49L opened
4210	Cut due to over-current of compressor
4220	Voltage anomaly
4230	Radiator panel temperature anomaly (TH8)
5101	Ambient temperature probe anomaly (TH1), indoor unit
5102	Liquid probe anomaly (TH2)
5103	Cond/Evap probe anomaly (TH5)
5104	Error detection in discharge temperature
5105	Outdoor probe error TH3
5106	Outdoor probe errorTH7
5107	Outdoor probe errorTH6
5110	Outdoor probe errorTH8
5202	Connector 63L opened
5300	Current probe error
6600	MNET duplicated address definition
6602	MNET Line transmission hardware error
6603	MNET BUS busy
6606	MNET Line transmission error
6607	MNET transmission error
6607	MNET without ack
6608	MNET transmission error
6608	MNET without response
6831	IR remote control transmission error (reception error)
6832	IR remote control transmission error (transmission error)
6840	Transmission error with the indoor/outdoor unit (reception error)
6841	Transmission error with the indoor/outdoor unit (transmission error)
6844	Error in inter-connection cable in the indoor/outdoor unit, indoor unit number deactivated (5 min or more)
6845	Error in inter-connection cable in the indoor/outdoor unit (cabling error, disconnection)
6846	Initial timer deactivated

In case you detect an error code not listed, contact your nearest Mitsubishi Electric technical support service for more information on the error meaning.

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice
IntesisBox® is a registered trademark of Intesis Software SL

Appendix A – Communication Objects Table

TOPIC	OBJECT NUMBER	NAME	LENGTH	DATAPOINT TYPE		FLAGS				FUNCTION
				DPT_NAME	DPT_ID	R	W	T	U	
On/Off	**0**	Control_ On/Off	1 bit	DPT_Switch	1.001		W	T		0 - Off; 1-On
Mode	**1**	Control_ Mode	1 byte	DPT_HVACContrMode	20.105		W	T		0 - Auto; 1 - Heat; 3 - Cool; 9 - Fan; 14 - Dry
	2	Control_ Mode Cool/Heat	1 bit	DPT_Heat/Cool	1.100		W	T		0 - Cool; 1 - Heat;
	3	Control_ Mode Cool & On	1 byte	DPT_Scaling	5.001		W	T		0% - Off; 0.1%-100% - On + Cool
	4	Control_ Mode Heat & On	1 byte	DPT_Scaling	5.001		W	T		0% - Off; 0.1%-100% - On + Heat
	5	Control_ Mode Auto	1 bit	DPT_Bool	1.002		W	T		1 - Auto
	6	Control_ Mode Heat	1 bit	DPT_Bool	1.002		W	T		1 - Heat
	7	Control_ Mode Cool	1 bit	DPT_Bool	1.002		W	T		1 - Cool
	8	Control_ Mode Fan	1 bit	DPT_Bool	1.002		W	T		1 - Fan
	9	Control_ Mode Dry	1 bit	DPT_Bool	1.002		W	T		1 - Dry
	10	Control_ Mode +/-	1 bit	DPT_Step	1.007		W			0 - Decrease; 1 - Increase
		Control_ Mode +/-	1 bit	DPT_UpDown	1.008		W			0 - Up; 1 - Down
Fan Speed	**11**	Control_ Fan Speed / 2 Speeds	1 byte	DPT_Scaling	5.001		W	T		0%-74% - Speed 1; 75%-100% - Speed 2;
		Control_ Fan Speed / 2 Speeds	1 byte	DPT_Enumerated	5.010		W	T		1 - Speed 1; 2 - Speed 2;

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice

IntesisBox® *is a registered trademark of Intesis Software SL*

Fan Speed	**11**	Control_ Fan Speed / 3 Speeds	1 byte	DPT_Scaling	5.001		W	T		0%-49% - Speed 1; 50%-82% - Speed 2; 83%-100% - Speed 3;
		Control_ Fan Speed / 3 Speeds	1 byte	DPT_Enumerated	5.010		W	T		1 - Speed 1; 2 - Speed 2; 3 Speed 3;
		Control_ Fan Speed / 4 Speeds	1 byte	DPT_Scaling	5.001		W	T		0%-37% - Speed 1; 38%-62% - Speed 2; 63%-87% - Speed 3; 88%-100% - Speed 4;
		Control_ Fan Speed / 4 Speeds	1 byte	DPT_Enumerated	5.010		W	T		1 - Speed 1; 2 - Speed 2; 3 Speed 3; 4 - Speed 4;
	12	Control_ Fan Speed Manual/Auto	1 bit	DPT_Bool	1.002		W	T		0 - Manual; 1 - Auto
	13	Control_ Fan Speed 1	1 bit	DPT_Bool	1.002		W	T		1 – Set Fan Speed 1
	14	Control_ Fan Speed 2	1 bit	DPT_Bool	1.002		W	T		1 – Set Fan Speed 2
	15	Control_ Fan Speed 3	1 bit	DPT_Bool	1.002		W	T		1 – Set Fan Speed 3
	16	Control_ Fan Speed 4	1 bit	DPT_Bool	1.002		W	T		1 – Set Fan Speed 4
	17	Control_ Fan Speed +/-	1 bit	DPT_Step	1.007		W			0 - Decrease; 1 - Increase
		Control_ Fan Speed +/-	1 bit	DPT_UpDown	1.008		W			0 - Up; 1 - Down
Vanes Up-Down	**18**	Control_ Vanes U-D / 4 pos	1 byte	DPT_Scaling	5.001		W	T		0%-37% - Pos1; 38%-62% - Pos2; 63%-87% Pos3; 88%-100% - Pos4;
		Control_ Vanes U-D / 4 pos	1 byte	DPT_Enumerated	5.010		W	T		1 - Pos1; 2 - Pos2; 3 - Pos3; 4 - Pos4;
		Control_ Vanes U-D / 5 pos	1 byte	DPT_Scaling	5.001		W	T		0%-29% - Pos1; 30%-49% - Pos2; 50%-69% Pos3; 70%-89% - Pos4; 90%-100% - Pos5

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice

IntesisBox® *is a registered trademark of Intesis Software SL*

		Control_ Vanes U-D / 5 pos	1 byte	DPT_Enumerated	5.010		W	T		1 - Pos1; 2 - Pos2; 3 - Pos3; 4 - Pos4; 5 - Pos5
	19	Control_ Vanes U-D Man/Auto	1 bit	DPT_Bool	1.002		W	T		0 – Manual; 1 - Auto
	20	Control_ Vanes U-D Pos1	1 bit	DPT_Bool	1.002		W	T		1 – Set Position 1
	21	Control_ Vanes U-D Pos2	1 bit	DPT_Bool	1.002		W	T		1 – Set Position 2
	22	Control_ Vanes U-D Pos3	1 bit	DPT_Bool	1.002		W	T		1 – Set Position 3
	23	Control_ Vanes U-D Pos4	1 bit	DPT_Bool	1.002		W	T		1 – Set Position 4
	24	Control_ Vanes U-D Pos5	1 bit	DPT_Bool	1.002		W	T		1 – Set Position 5
	25	Control_ Vanes U-D Swing	1 bit	DPT_Bool	1.002		W	T		0 – Off; 1 – Swing
	26	Control_ Vanes U-D +/-	1 bit	DPT_Step	1.007		W			0 - Decrease; 1 - Increase
		Control_ Vanes U-D +/-	1 bit	DPT_UpDown	1.008		W			0 - Up; 1 - Down
Temperature	**27**	Control_ Setpoint Temperature	2 byte	DPT_Value_Temp	9.001		W	T		(ºC)
	28	Control_ Setpoint Temp +/-	1 bit	DPT_Step	1.007		W			0 - Decrease; 1 - Increase
		Control_ Setpoint Temp +/-	1 bit	DPT_UpDown	1.008		W			0 - Up; 1 - Down
	29	Control_ Ambient Temperature	2 byte	DPT_Value_Temp	9.001		W	T		(ºC)
Timeout	**30**	Control_ Window Contact Status	1 bit	DPT_OpenClose	1.009		W	T		0 - Open; 1 - Closed
		Control_ Switch Off Timeout	1 bit	DPT_Start	1.010		W	T		0 - Stop; 1 - Start
	31	Control_ Occupancy	1 bit	DPT_Occupancy	1.018		W	T		0 - Not Occupied; 1 - Occupied
	32	Control_ Sleep Timeout	1 bit	DPT_Start	1.010		W	T		0 - Stop; 1 - Start
Locking	**33**	Control_ Lock Remote Control	1 bit	DPT_Bool	1.002		W	T		0 - Unlocked; 1 - Locked

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice

IntesisBox® *is a registered trademark of Intesis Software SL*

	34	Control_ Lock Control Objects	1 bit	DPT_Bool	1.002		W	T		0 - Unlocked; 1 - Locked
Special Modes	**35**	Control_ Power Mode	1 bit	DPT_Start	1.010		W	T		0 - Stop; 1 - Start
	36	Control_ Econo Mode	1 bit	DPT_Start	1.010		W	T		0 - Stop; 1 - Start
	37	Control_ Additional Heat	1 bit	DPT_Start	1.010		W	T		0 - Stop; 1 - Start
	38	Control_ Additional Cool	1 bit	DPT_Start	1.010		W	T		0 - Stop; 1 - Start
Scenes	**39**	Control_ Save/Exec Scene	1 byte	DPT_SceneControl	18.001		W	T		0 to 4 - Exec. Scene 1 to 5; 128 to 132 - Save Scene 1 to 5
	40	Control_ Store Scene1	1 bit	DPT_Bool	1.002		W			1 - Store Scene
	41	Control_ Store Scene2	1 bit	DPT_Bool	1.002		W			1 - Store Scene
	42	Control_ Store Scene3	1 bit	DPT_Bool	1.002		W			1 - Store Scene
	43	Control_ Store Scene4	1 bit	DPT_Bool	1.002		W			1 - Store Scene
	44	Control_ Store Scene5	1 bit	DPT_Bool	1.002		W			1 - Store Scene
	45	Control_ Execute Scene1	1 bit	DPT_Bool	1.002		W	T		1 - Execute Scene
	46	Control_ Execute Scene2	1 bit	DPT_Bool	1.002		W	T		1 - Execute Scene
	47	Control_ Execute Scene3	1 bit	DPT_Bool	1.002		W	T		1 - Execute Scene
	48	Control_ Execute Scene4	1 bit	DPT_Bool	1.002		W	T		1 - Execute Scene
	49	Control_ Execute Scene5	1 bit	DPT_Bool	1.002		W	T		1 - Execute Scene
Disabling	**50**	Control_ Disable Input 1	1 bit	DPT_Bool	1.002		W	T		0 - Enable; 1 - Disable
		Control_ Disable Input 1	1 bit	DPT_Enable	1.003		W	T		0 - Disable; 1 - Enable
	51	Control_ Disable Input 2	1 bit	DPT_Bool	1.002		W	T		0 - Enable; 1 - Disable

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice

IntesisBox® *is a registered trademark of Intesis Software SL*

URL http://www.intesis.com
Email info@intesis.com
tel +34 938047134

		Control_ Disable Input 2	1 bit	DPT_Enable	1.003		W	T		0 - Disable; 1 - Enable
	52	Control_ Disable Input 3	1 bit	DPT_Bool	1.002		W	T		0 - Enable; 1 - Disable
		Control_ Disable Input 3	1 bit	DPT_Enable	1.003		W	T		0 - Disable; 1 - Enable
	53	Control_ Disable Input 4	1 bit	DPT_Bool	1.002		W	T		0 - Enable; 1 - Disable
		Control_ Disable Input 4	1 bit	DPT_Enable	1.003		W	T		0 - Disable; 1 - Enable
On/Off	**54**	Status_ On/Off	1 bit	DPT_Switch	1.001	R		T		0 - Off; 1-On
Mode	**55**	Status_ Mode	1 byte	DPT_HVACContrMode	20.105	R		T		0 - Auto; 1 - Heat; 3 - Cool; 9 - Fan; 14 - Dry
	56	Status_ Mode Cool/Heat	1 bit	DPT_Heat/Cool	1.100	R		T		0 - Cool; 1 - Heat
	57	Status_ Mode Auto	1 bit	DPT_Bool	1.002	R		T		1 - Auto
	58	Status_ Mode Heat	1 bit	DPT_Bool	1.002	R		T		1 - Heat
	59	Status_ Mode Cool	1 bit	DPT_Bool	1.002	R		T		1 - Cool
	60	Status_ Mode Fan	1 bit	DPT_Bool	1.002	R		T		1 - Fan
	61	Status_ Mode Dry	1 bit	DPT_Bool	1.002	R		T		1 - Dry
	62	Status_ Mode Text	14 byte	DPT_String_8859_1	16.001	R		T		ASCII String
Fan Speed	**63**	Status_ Fan Speed / 2 Speeds	1 byte	DPT_Scaling	5.001		W	T		50%- Speed 1; 100% - Speed 2;
		Status_ Fan Speed / 2 Speeds	1 byte	DPT_Enumerated	5.010		W	T		1 - Speed 1; 2 - Speed 2;
		Status_ Fan Speed / 3 Speeds	1 byte	DPT_Scaling	5.001		W	T		33% - Speed 1; 67% - Speed 2; 100% - Speed 3;
		Status_ Fan Speed / 3 Speeds	1 byte	DPT_Enumerated	5.010		W	T		1 - Speed 1; 2 - Speed 2; 3 Speed 3;

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice

IntesisBox® *is a registered trademark of Intesis Software SL*

		Status_ Fan Speed / 4 Speeds	1 byte	DPT_Scaling	5.001		W	T		25% - Speed 1; 50% - Speed 2; 75% - Speed 3; 100% - Speed 4;
		Status_ Fan Speed / 4 Speeds	1 byte	DPT_Enumerated	5.010		W	T		1 - Speed 1; 2 - Speed 2; 3 Speed 3; 4 - Speed 4;
	64	Status_ Fan Speed Manual/Auto	1 bit	DPT_Bool	1.002	R		T		0 – Manual; 1 - Auto
	65	Status_ Fan Speed 1	1 bit	DPT_Bool	1.002	R		T		1 – Fan is in speed 1
	66	Status_ Fan Speed 2	1 bit	DPT_Bool	1.002	R		T		1 – Fan is in speed 2
	67	Status_ Fan Speed 3	1 bit	DPT_Bool	1.002	R		T		1 - Fan is in Speed 3
	68	Status_ Fan Speed 4	1 bit	DPT_Bool	1.002	R		T		1 - Fan is in Speed 4
	69	Status_ Fan Speed Text	14 byte	DPT_String_8859_1	16.001	R		T		ASCII String
Vanes Up-Down	**70**	Status_ Vanes U-D / 4 pos	1 byte	DPT_Scaling	5.001	R		T		25% - Pos1; 50% - Pos2; 75% - Pos3; 100% - Pos4;
		Status_ Vanes U-D / 4 pos	1 byte	DPT_Enumerated	5.010	R		T		1 - Pos1; 2 - Pos2; 3 - Pos3; 4 - Pos4;
		Status_ Vanes U-D / 5 pos	1 byte	DPT_Scaling	5.001	R		T		20% - Pos1; 40% - Pos2; 60% - Pos3; 80% - Pos4; 100% - Pos5
		Status_ Vanes U-D / 5 pos	1 byte	DPT_Enumerated	5.010	R		T		1 - Pos1; 2 - Pos2; 3 - Pos3; 4 - Pos4; 5 - Pos5
	71	Status_ Vanes U-D Man/Auto	1 bit	DPT_Bool	1.002	R		T		0 – Manual; 1 - Auto
	72	Status_ Vanes U-D Pos1	1 bit	DPT_Bool	1.002	R		T		1 - Position 1
	73	Status_ Vanes U-D Pos2	1 bit	DPT_Bool	1.002	R		T		1 - Position 2
	74	Status_ Vanes U-D Pos3	1 bit	DPT_Bool	1.002	R		T		1 - Position 3

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice

IntesisBox® *is a registered trademark of Intesis Software SL*

	75	Status_ Vanes U-D Pos4	1 bit	DPT_Bool	1.002	R		T		1 - Position 4
	76	Status_ Vanes U-D Pos5	1 bit	DPT_Bool	1.002	R		T		1 - Position 5
	77	Status_ Vanes U-D Swing	1 bit	DPT_Bool	1.002	R		T		0 – Off; 1 – Swing
	78	Status_ Vanes U-D Text	14 byte	DPT_String_8859_1	16.001	R		T		ASCII String
Temperature	**79**	Status_ AC Setpoint Temp	2 byte	DPT_Value_Temp	9.001	R		T		(ºC)
	80	Status_ AC Return Temperature	2 byte	DPT_Value_Temp	9.001	R		T		(ºC)
Error	**81**	Status_ Error/Alarm	1 bit	DTP_Alarm	1.005	R		T		0 - No Alarm; 1 - Alarm
	82	Status_ Error Code	2 byte	Enumerated		R		T		0 - No Error; Any other see user's manual
	83	Status_ Error Text code	14 byte	DPT_String_8859_1	16.001	R		T		4 char ME Error; Empty - none
Special Modes	**84**	Status_ Power Mode	1 bit	DPT_Switch	1.001	R		T		0 - Off; 1-On
	85	Status_ Econo Mode	1 bit	DPT_Switch	1.001	R		T		0 - Off; 1-On
	86	Status_ Additional Heat	1 bit	DPT_Switch	1.001	R		T		0 - Off; 1-On
	87	Status_ Additional Cool	1 bit	DPT_Switch	1.001	R		T		0 - Off; 1-On
Counter	**88**	Status_ Operation Hour Counter	2 byte	DPT_Value_2_Ucount	7.001	R		T		Number of operating hours
Scene	**89**	Status_ Current Scene	1 byte	DPT_SceneNumber	17.001	R		T		0 to 4 - Scene 1 to 5; 63 - No Scene
Binary Inputs	**90**	Status_ Inx - Switching	1 bit	DPT_Switch	1.001	R		T		0 - Off; 1-On
	92	Status_ Inx – Dimming - On/Off	1 bit	DPT_Switch	1.001	R		T		0 - Off; 1 - On
	94	Status_ Inx – Shut/Blind - Step	1 bit	DPT_ShutterBlinds	1.023	R		T		0 – Step Up; 1 – Step Down
	96									

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice

IntesisBox® *is a registered trademark of Intesis Software SL*

		Status_ Inx – Value	1 byte	DPT_Value_1_Ucount	5.010	R		T		1 byte unsigned value
		Status_ Inx – Value	2 byte	DPT_Value_2_Ucount	7.001	R		T		2 byte unsigned value
		Status_ Inx – Value	2 byte	DPT_Value_2_Count	8.001	R		T		2 byte signed value
	91	Status_ Inx – Value	2 byte	DPT_Value_Temp	9.001	R		T		Temperature (ºC)
	93	Status_ Inx – Value	4 byte	DPT_Value_4_Ucount	12.001	R		T		4 byte unsigned value
	95	Status_ Inx – Dimming – Step(%)	1 bit	DPT_Control_Dimm.	3.007	R		T		Dimming step
	97	Status_ Inx - Shut/Blind -Move	1 bit	DPT_ShutterBlinds	1.023	R		T		0 – Move Up; 1 – Move Down
Legacy	**98**	Legacy_ Mode	1 byte	Enumerated		R		T		0 - Auto; 1 - Heat; 2 - Dry; 3 - Fan; 4 - Cool
	99	Legacy_ Fan Speed	1 byte	Enumerated		R		T		0 – Auto; 1..4 – Speed 1..4
	100	Legacy_ Vane Up-Down	1 byte	Enumerated		R		T		0 – Auto; 1..5 – Pos 1..5; 6 - Swing

© Intesis Software S.L. - All rights reserved
This information is subject to change without notice

IntesisBox® *is a registered trademark of Intesis Software SL*